

Bulldog BR20 Minilock Fitting Instructions For Bradley Autohead 2750/3500 Hitch

Please Note: To remove the lock bolt, hold the head of the bolt to prevent it from turning, push the key in and turn ¼ turn anti-clockwise, pull out the lock bolt with the key. Place aside carefully. Do not allow dirt to enter the lock.



1. Lift the handle and insert the dummy ball ensuring the handle returns to the fully down position.



2. Tilt the rear of the red hitchlock cover back and “feed” the handle through the slot provided.



3. Pivot the red cover down towards the front so it rests on top of the hitch.



4. With the lock bar in the unlocked position, insert it into the red cover and push it into the lock housing. When in position, turn the key ¼ turn clockwise to lock and remove key.

Note: If the hitchlock is required when the trailer is attached to a tow vehicle, the dummy ball is not required.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.



Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray outside of lock body with WD40 (or equivalent) minimum every four months.

Key Security. Enter your key number here:

IMPORTANT - Your Bulldog product is supplied with two keys. Make a note of your personal key number in the space provided above and **keep it in a safe place**. Should you lose your keys, replacements can only be obtained from the manufacturer through your dealer.