



### STEP 1

POSITION THE CLAMP AROUND THE TYRE BY HOOKING ONE ARM THEN THE OTHER AROUND BASE OF TYRE.



COVER PLATE

### STEP 2

PULL COVER PLATE UP SO THAT IT IS CENTRAL TO THE WHEEL HUB AND THE CLAMP ARMS ARE TOUCHING THE GROUND.



### STEP 3

HOOKE THE THIRD ARM OVER AND BEHIND THE TYRE AND SLIDE DRILLED BAR INTO COVER PLATE. ADJUST UNTIL THE CLAMP IS TIGHT ON THE TYRE. PUSH LIGHTLY ON THE PUSH LOCK AND ADJUST ARM UNTIL HOLES LINE UP AND THE LOCK CLICKS INTO PLACE.



**WARNING:**  
UNDER NO CIRCUMSTANCES  
ATTEMPT TO DRIVE THE VEHICLE  
WHILST THE CLAMP IS FITTED.